



**SAVAGE  
BROS. CO.**  
S I N C E 1 8 5 5

*A 21<sup>st</sup> Century Company . . . with 19<sup>th</sup> Century Craftsmanship*

1125 Lunt Avenue  
Elk Grove Village, IL 60007-5023 USA

Phone: 847-981-3000  
USA Fax: 800-2-SAVAGE  
World Fax: + 847-981-3010  
E-mail: info@savagebros.com  
Web: www.savagebros.com

## TRANSFER PUMP OPERATOR CONTROL OPTIONS

### Standard Pump Configuration – operator control in pump head

- PUMP ON/OFF Switch
- HEAT ON/OFF Switch
- CYCLE INTERVAL Control – frequency of pump cycles



### Pump with Integrated Control Module – right or left hand orientation

- PUMP controlled from CYCLE TIMER or REMOTE SWITCH (level sensor for example)
- HEAT ON/OFF Switch
- CYCLE TIMER – ability to set independent ON and OFF intervals



## External On-Tank Control Cover - operator control enclosure mounted on tank sidewall

- Pump OFF/WARM/ON Switch – leave pump warm when not operating
- PUMP controlled from CYCLE TIMER or REMOTE SWITCH (level sensor for example)
- VARIABLE HEAT control
- CYCLE TIMER – ability to set independent ON and OFF intervals
- CYCLE COUNTER – re-settable counter to track total transfer



Savage tanks ordered with transfer pump and External On-Tank Control Cover include sanitary clamp-on fitting to hold control enclosure.

We offer stainless steel straps with fitting to mount control enclosure to existing tanks.

